

GEN III ECLIPSE TRANSIT COVER REPLACEMENT INSTRUCTIONS

DARCHE®

TOOLS REQUIRED:

- Phillips head screwdriver
- 5mm Allen key
- 13mm wrench
- Knife or scissors

STEP 1

Fully unzip your transit cover and remove the 4 screws securing the transit cover to the base of the awning. Slide the transit cover out from the sailtracks.



If you have an ECO Eclipse awning or a Tropical Transit Cover the rectangular backing plates at each end of the awning must also be removed before removing the transit cover. Replace and loosely attach the backing plates.

STEP 2

Place your awning in the replacement transit cover. Ensure that the cover is not twisted, the zip is at the bottom of the awning, and that it does not require undue force to fully zip up the cover.



STEP 3

Cut a pair of perpendicular incisions in the transit cover at each location corresponding with the 8mm bolts for the backing plate (8 total). The incisions should be as small as possible while allowing the 8mm bolts to be pushed through. It is recommended that this step be done with the transit cover fully zipped up.



GEN III ECLIPSE TRANSIT COVER REPLACEMENT INSTRUCTIONS

DARCHE®

STEP 4

Remove the backing plates from the awning and reattach them on the outside of the transit cover.



STEP 5

Unzip the transit cover and insert the awning mounting bolts into the mounting channels after removing the rubber grommets. Locate the bolts to suit your vehicle and roof rack then cut a pair of perpendicular incisions in the transit cover at each location corresponding with the mounting bolts. Re-insert the grommets.



STEP 6

Attach your mounting brackets to your awning.



Designed and tested in Australia for Australian conditions.

A brand by Charles Parsons.

Telephone 1300 367 695 | Email: info@DARCHE.com.au
75 Heyington Avenue, Thomastown VIC 3074, Australia.

DARCHE: LEADERS IN OUTDOOR DESIGN. PROUDLY AUSTRALIAN.

Due to our policy of continual product development, the specifications, colours and features may vary.