

ASSEMBLY INSTRUCTIONS

W a n d e r e r 

OVERLAND 10P DOME TENT



PLU: 580884

PARTS LIST:

DESCRIPTION	QTY
Tent	1
Fly	1
Fibreglass Pole	3
Awning Pole	3
Steel Pegs	21
Carry Bag	1
Guy Ropes	3

Fibreglass Pole



Awning Pole



Carry Bag



Pegs




Guy Ropes

SET UP INSTRUCTIONS


STEP 1

Take out of the inner tent and spread out on the ground then peg down. Ensure all the doors and windows are open.




STEP 2

Then using the three fibreglass poles (one black and two grey) slide through sleeves and fix both ends on pin and ring one by one. Attach tent to poles by clips.



STEP 3


Take flysheet and drape over inner tent with two doors in correct direction. Then fix the pegs and guy ropes.



W a n d e r e r 

STEP 4

If using awning use steel upright poles and extra guy ropes to secure.



WARNING

DO NOT use any form of flame or fuel burning appliances, heaters, candles or matches inside the tent.

DO NOT set up near open flame.

DO NOT use soap or detergent. Clean only with cold water and a brush.

DO NOT expose to petrol, oil or solvents.

DO NOT spray insecticides onto the tent.

This tent is not designed to be a permanent dwelling. It is designed to be used as a portable and temporary structure.

Manufactured and packaged for SRGS PTY LTD
ABN 23 113 230 050
751 Gympie Road, Lawnton, Queensland 4501, Australia

MADE IN CHINA