




10mm


Components



Assembly



Child Restraint





289.5mm


216mm

WARNING:

- Always use the chair on a flat, even and horizontal floor and do not elevate the chair on any structure or table.
- Always position the chair away from furniture, walls, hot surfaces and liquids, window covering cords, and electrical cords and position the chair away from furniture when the chair is not being used at a table with a tray removed.
- The chair should only be used in an upright position once the child is capable of reliably and consistently sitting upright.
- Always use the chair for children weighing no more than 15kg.
- Always check the chair before use.
- Do not use the chair if it is not working correctly.
- The tray is not designed to hold the child in the chair.



Tray Removal & Storage



Adjust the Straps