

KICKASS



JET FAN SUPER BLOWER

OWNER'S MANUAL

KAJETFAN

V1.1

TABLE OF CONTENTS

SAFETY INFORMATION -----	1
PRODUCT SPECIFICATIONS -----	2
WHAT'S IN THE BOX -----	2
UNDERSTANDING YOUR JET FAN -----	3
RECHARGING YOUR JET FAN -----	4
USING YOUR JET FAN -----	5
STORING YOUR JET FAN -----	5

SAFETY INFORMATION

- DO NOT use the JET fan for mattress inflation, as this could cause the motor to overheat and fail.
- DO NOT block the air openings of the machine while in use.
- DO NOT use the product with wet hands.
- DO NOT allow the product to come into contact with any liquid.
- DO NOT leave it out in the rain or near moisture.
- DO NOT expose the product to moisture or liquids.
- DO NOT drop or insert objects into any openings.
- DO NOT place the product near heat sources.
- DO NOT operate the product near flammable substances such as gas or fuel.
- DO NOT operate the product if it has been dropped or damaged.
- Never use a damaged charging cable.
- Cease to operate the unit immediately if abnormal operation is observed.
- DO NOT disassemble the product. Warranty will be void.
- This Jet Fan is not waterproof. Only use a soft dry cloth to clean it.
- DO NOT use sharp objects to clean the air inlet and outlets.
- DO NOT direct air towards eyes, ears, mouth or other sensitive areas.
- The jet fan should never be left unattended after powered on.
- Keep the jet fan out of the reach of children or pets

PRODUCT SPECIFICATIONS

Battery:	11.1V/4000mAh Lithium
USB C Charging Input:	5V/2A, 9V/2A 18W Max
Run Time:	From 15 Minutes To 2 Hours Depending On Speed Setting
Charging Time:	3 Hours
3 Levels Of Motor Speed:	36000, 60000 And 90000rpm
3 Levels Of Air Speed:	20 Meters Per Second, 50 Meters Per Second And 70 Meters Per Second
Product Dimensions:	160 X 80 X 50 mm
Product Weight:	518g
Certification:	IEC 62133, AS/NZS 60335.1:2022

WHAT'S IN THE BOX

CARRY BAG



**USB C TO USB A
CHARGING CABLE**



JET FAN

UNDERSTANDING YOUR JET FAN



RECHARGING YOUR JET FAN



- Fully charge your jet fan before first of use.
- Always turn off the jet fan before charging.
- Insert one end of the provided USB C to USB A cable into the USB C port on the Jet fan, and the other end into a DC adapter with an USB A output.
- The red charging indicator light will flash when the battery capacity is low.
- The red charging indicator light will remain solid when the battery is recharging.
- The charging indicator light will become green and remain on after the battery is fully charged.
- The charging time is about 3 hours.

Notes:

- The maximum charging input on the unit is 9V/2A 18W Max.
- The unit is only compatible with a USB C to USB A cable.
- The unit cannot work while charging.
- It's not recommended to charge the unit while the ambient temperature is over 40 degrees.

USING YOUR JET FAN



Turn On: Press and hold the power control button for 3 seconds to turn on the jet fan.

Change Speed: Short press the power control button to cycle through the 3 speed levels.

Speed Control: Short press the speed control button to turn each speed level on or off.

Turn Off: Press and hold the power button for 3 seconds to turn off the jet fan.

Auto Shut-Off: The jet fan will automatically turn off after 5 minutes of inactivity to conserve battery power.

STORING YOUR JET FAN

- Ensure your jet fan is turned off.
- Store the jet fan in the provided storage bag, designed to be tough and durable for optimal protection.
- Keep the bag in a cool, dry place away from direct sunlight.



**KickAss is a registered trademark of
KickAss Products Pty Ltd**

**Designed & imported by
KickAss Products Pty Ltd
39 Iris Place, Acacia Ridge, QLD 4110
Australia**

Made in China

