



Enjoy it.

CONTENTS

General Safety	4
Product Overview	6
Setup	7
Remote Control	8
RC Pairing	9
First Time Setup	10
Android TV - Home	13
Discover	15
Google Play	17
Google Assistant	18
Customer Helpline	Last Page

GENERAL SAFETY

Read this manual thoroughly before you start using this product. Store this manual, the completed warranty card, your receipt and the product packaging.

Please follow all instructions and take notice of all warnings.

- Please beware that Dust could accumulate over time on the unit and cause it to generate heat and or deteriorate insulation, which in turn may result in an electrical fire.
- The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or young children of any age, They must be supervised product by a person responsible for their safety.
- Batteries from the remote control must be only removed by an adult, the adult must ensure to keep them out of reach of infants and children. Seek medical attention immediately if a child has swallowed a battery.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
- Please ensure to contact our call center for any repair or service required for the products.

GENERAL SAFETY (Cont.)

Please make sure upon positioning this product, the place is:

- Not wet or damp and Well ventilated
- · Away from direct sunlight or heaters.
- · Away from splashes or food.
- Protected from excessive dust or grease.
- Do not install this product near heat sources such as radiators, stoves or other audio visual equipment that produce heat.




"HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC."

Google, Android, Google Play, YouTube and other marks are trademarks of Google LLC.

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

PRODUCT OVERVIEW



- ANDROID TV DEVICE
- POWER ADAPTOR
- MICRO USB CABLE

- MANUAL/WARRANTY
- REMOTE CONTROL
- HDMI EXTENDER

SETUP

Step 1

Plug in the Android TV device HDMI into the back of the TV HDMI Port on your TV.

Step 2

Plug in the Micro USB Power Cable (provided) into the side of the Android TV Device labeled. Then plug in the USB-A side into the power adaptor (provided) and then into a power outlet.

Step 3

Once you have connected the HDMI cable and power cable of the Android TV Device, make sure to change the TV input to the HDMI port you inserted your Android TV Device into.

Step 4

Now you can follow First time setup process of the Android TV Device.

Refer to page 8 for illustration.


REMOTE CONTROL

	Button	Description		Button	Description
01	(1)	POWER ON/OFF	09	٥	SETTINGS
02	0	DIRECTION/NAVIGATION	10	•	номе
03	0	ок	11		GOOGLE ASSISTANT
04	(GO BACK	12	NETFLIX	OPEN NETFLIX
05	Ğ	OPEN LIVE TV EPH	13	► YouTube	OPEN YOUTUBE
06	+ -	VOLUME UP / DOWN	14	Google Play	OPEN GOOGLE PLAY
07	^ ~	CHANNEL UP / DOWN	15	prime video	OPEN PRIME VIDEO
08	■ ×	MUTE	16	N.	TO ADD AN ENTITY TO WATCHLIST
08	∌	INPUT			

FIRST TIME SETUP - RC PAIR


When you first turn on your Android TV Device. Pairing instrucitons will appear on the screen.

Please follow the pairing and setup instructions.



FIRST TIME SETUP (cont.)

2. Select your desired language (ENGLISH is recommended)



3. You can quickly set up your streaming device using your Google Account on your smartphone.

Otherwise you may skip this feature and manually enter your wifi password to continue the setup process.

FIRST TIME SETUP (cont.)

- 4. Choose your Wi-Fi Network and enter in the password.
- 5. Sign in with your Google Account, if you do not have a Google Account, select "Skip".

Note: You must have a Google Account to be able to access Google Play and download/install additional apps. With the software upgrade, some models do not provide the skip option.

- Accept Terms of Service, Location (for weather and other user experiences).
- 7. Choose a Device name: BPTV10 or other suggestions.

FIRST TIME SETUP (cont.)

Informational screens will now appear, you can scroll through steps by press "RIGHT" directional button to continue.






ANDROID TV - HOME

Once setup is completed, you will arrive at the Android TV home page. **Your Pre-installed apps are:** Netflix, YouTube and Google Play.

Note: Below home page is REFERENCE ONLY.



ANDROID TV - HOME (Cont.)

- Press the Google Assistant button on your remote to do more on your TV with your voice.
- HOME Main page to enter Live TV, view your pre-installed and downloaded applications.
- SHOP Available purchased content collected in this section.
 I.E. rented movie.
- DISCOVER Sign into your Google Account to get recommendations from your streaming services - organized into topics and genres based on what you watch.
- 5 APPS Apps you have downloaded and apps you can search for to install
- 6. **NOTIFICATION -** Notification content is sent by Google.
- 7. **SETTINGS -** Select this if you want to access TV settings.
- 8. **TIME -** Displaying current time.
- Each row past this point will display recommended content from the apps you already have installed.
 - **Add Apps -** At the end of this row of apps, Select the + box and add your app that you have downloaded and installed to the home screen of your Android TV.
- 10. Movies or Shows available to play next.

DISCOVER

Simplify your entertainment experience with Android TV. Discover 700,000+* movies and shows in one place.



DISCOVER (Cont.)


If you havent already signed into Google Play using your Google Account. When selecting **DISCOVER** tab on the top of home page, you will be prompted to sign in.

Note: if already signed in, your Google Account will already appear.

- Once signed into Google, you can select the apps you want recommendations for within the **DISCOVERY** section of Android TV.
- Select (Tick) the apps you would like recommendations for.
- 3. Allow up to 10 seconds for Android TV to gather recommendations.
- DISCOVER section will now display Movies or TV Shows recommended for you to watch.

APP & GOOGLE PLAY

Sign in with a Google Account and download all your favorite apps and games on Google Play.




GOOGLE ASSISTANT

Press the Google Assistant button on your remote to do more on your TV with your voice.

Ask Google to search for the latest blockbuster, stream shows, or open multiplayer games. Have it dim the lights by connecting smart home devices. Manage tasks and see your calendar. Or ask it questions and see the answers on your TV.





PAGE LEFT BLANK ON PURPOSE



CUSTOMER SUPPORT:

info@ayonz.com / 02 8279 8606

DISTRIBUTED BY:

Ayonz Pty Ltd