


RECHARGEABLE MINI 3-IN-1 HIKE PUMP


Please read this user manual carefully before use and please keep it for future reference.

Please charge the battery at least every 6 months to ensure good battery performance.



PRODUCT OVERVIEW

1. Foldable handle
2. Air pump switch
3. Illuminator switch
4. TYPE-C charging port
5. Battery indicator
6. Type-C USB CABLE
7. Deflation port
8. Inflation port
9. Air nozzles
10. LED light




SPECIFICATIONS

Product Size: L5.5*W5.2*H9cm	Net Weight: 126g
Material: ABS + PP + Silicone Gel	Cable: USB Type-C
Input: DC 5V / 1A	Battery: 3.7V 1200mWh
Charging Time: ~1.5Hours	Usage Time: ~10Minutes

OPERATING INSTRUCTIONS



1) Choose the appropriate nozzle, insert it into the air vent (on the side), and connect it to the product you want to inflate. Double click the "  " button, and the air pump will start inflating.



2) Choose the appropriate nozzle, insert it into the top suction hole, connect it to the product you want to deflate, and double click the "  " button to start the air pump for deflation.


Method to turn on the light

1. Double click the "☘" button to turn on the LED light switch and activate the cool light.
2. Click the "☘" button once to switch to SOS distress signal light.
3. Click the "☘" button again to shut down the device.

When the LED light is set to cool light, hold down the switch to change the dimmer settings.

Note: When the product is hanging by the hook, the illumination area is 10-20m².

BATTERY & CHARGING



- Lift the soft rubber cover at the "☘" and insert the TYPE-C charging cable to charge the air pump. The battery indicator lights up, and as the battery level increases, three lights will light up in sequence. Once fully charged, the green light will remain on. The charging time is 1.5 hours.
- Please use the Type-C USB cable supplied with this product to charge. Please make sure to use a 5V USB interface for charging.
- When only one indicator is on, it is recommended to charge the product in time. The indicators will flash during charging, and all the indicators will be on when the product is fully charged.
- Make sure the battery is fully discharged before the first charge. After the battery is discharged, the internal temperature is too high. It is recommended to cool down before charging. Ensure the product is charged every six months, for optimal battery life.
- Do not dispose of this product in a general waste bin. Please see your local council for the best method of disposal.

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions and warnings carefully before use.

- Maximum working air pressure: < 0.5 PSI.
- Do not expose to moisture, leave out in the elements or immerse in water.
- Do not use product in extreme humidity or in proximity to flames. Store in a cool, dry place.
- Keep away from heat, direct sunlight, moisture, and dust.
- Do not look into the inflation port/deflation port or face it when using it.
- Do not attempt to put your hands or fingers into the inflation port and the deflation port at any time.
- Be careful not to allow sand, small stones and other foreign objects to be drawn into the inflation port or deflation port when in use.
- Never direct the aerating or exhausting ports toward the eyes.
- Use in environments below 40°C ambient temperature.
- Turn off the air pump before charging. The Type-C USB data cable is used for charging only. Do not use this product during charging.
- Switch off and store out of children's reach when not in use.
- This is a high-volume, low-pressure pump. It is not intended for continuous use.
- Allow the pump to cool for 10 minutes after 5 minutes of continuous use.
- Do not dispose of air pump and its batteries in general waste bins. Check your local council waste facility for proper disposal instructions.
-  Disposal: Do not dispose of this product as unsorted municipal waste. The waste must be collected separately for special disposal.

WARNING

- Seek help from the professional personnel for troubleshooting, when the product is faulty or the battery is damaged to reduce risks.
- This appliance is to be used by adults only, this is not to be used by children, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children must be monitored during the operation of this device, and are not allowed to play with this device.
- Never keep it unattended when in use.
- Cleaning and user maintenance shall not be made by children without supervision.
- This product contains batteries that are non-replaceable.
- Do not dispose of the product in fire; may cause explosion or battery leakage.

PLU: 713642 CODE: HT-462C

Manufactured and packaged for SRGS PTY LTD

ABN 23 113 230 050, 6 Coulthards Avenue, Strathpine QLD 4500, Australia

MADE IN CHINA