

FLY REPELLENT FAN

User Manual

HOW IT WORKS

- This unit is designed to repel flies from your table. The rotating soft plastic blades simulate a threat to flies and they will stay away. It can sit flat on a table or hang from above.

SPECIFICATION

- Power: 2x AA batteries (not included) or DC 5V input (USB cable included)
- Product Size: 8.2 x 8.2 x 24cm


HOW TO USE

1. Open the battery cover at the bottom of the Fly Repellent Fan, then insert batteries, make sure that the polarity is correct.
2. Switch the Fan ON.
3. The soft plastic blades will rotate and expand to keep away flies from food in the vicinity.

REMARK

1. When DC power is connected, battery power is automatically disconnected.
2. Pay attention to the installation direction.

FIG.



WARNING

- This is not a toy, keep away from children.
- When not in use, remove battery from unit.
- This is an electrical product, please keep it away from water and liquid.