

English Version

CONVERTIBLE ROCKING CHAIR INSTRUCTIONS


TO CONVERT CHAIR TO ROCKING STYLE FOLLOW THESE INSTRUCTIONS:



1. Remove 2 rockers from separate accessory bag.
2. Position rockers with "FRONT" stickers facing front of the chair. The rockers are interchangeable.
3. Hold front chair leg and push down into black plastic base on rocker until it clicks into place.
4. Hold back chair leg and push down into black plastic base on rocker until it clicks into place.
5. Repeat Steps 3 and 4 on remaining chair leg.
6. Enjoy your rocking chair.



Remove 2 rockers from separate accessory bag.



Hold chair leg and push down into black plastic base on rocker until it clicks into place.

TO REMOVE THE ROCKERS FROM CHAIR FOLLOW THESE INSTRUCTIONS:

1. Depress green button on front rocker and grab chair leg and pull in upwards motion.
2. Depress green button on back rocker and grab chair leg and pull in upwards motion.
3. Repeat Steps 1 and 2 on remaining chair legs.
4. Place detached rockers in separate carry bag and insert into larger chair carry bag for easy transport.
5. Enjoy your stationary chair.



Depress green buttons to release rockers.

PLU: 631641

16cm

16cm